

1



Line up neck over stud screws. The neck will overhang the rear of the base.

2



Push the neck forward as far as possible.

3



Hold the front of the base firmly and use your fist to forcefully seat neck into stud screws.

4



The neck will sit approximately .25" in from the rear edge. There should be no movement of the neck if it is assembled correctly.